## CAM SYNC / 8771 ICT



## CAM SYNC SET UP:

The magnet should be just entering the pickup at approximately 90 - 110 degrees before #1 TDC.

If finer adjustment is needed, move the gear on the shaft spline.

1 turn out from touching.