COMMAND MODULE 4.0

Notes:

- Make all new files from carfile.ema out of this box (do not use old files)
- Rev-Limiter now built-in. 2 step rev-limit also.
- Display turns red when safety box is tripped.
- File transfer menu has changed.
- Air regulators and Timing Controller have curve shift capabilities.
- Updated software available on www.electrimotion.com.
- Racepak voltage output levels have changed from SB001a

Standby Analog output   =   0.125v

Fire Bottle/Driver Button Analog out = +0.125v change

Tether Analog output   = +0.25v   change

RF Analog output   = +0.75v   change

Command Module Safety Box Input Harness

B B B B B

Tether FB

Small BLK Wires
to ground

Tether Cord Input

Fire bottle

or

Driver switch

Command Module Safety Box Output Harness

B	B	B	B	B	B		
IGN	Chute	Fuel		Xtra	Analog		

To

CM Ignition
enable

RacePak 1-5v

3 pin Grey

Chute and fuel

Deploy