

3rd Gen Timer (RPM and Pressure)

Lenco Start Hookup Diagram:

Warning!!! Do not plug the red plug into the 8168 female amp plug with black and gray wires. This will fry the timer and 8168.

